

HOW TO ADJUST YOUR PINZA ROTARY TYING PLIERS TO PROPER WIRE SIZE



1. Cut wire approximately 3" long



2. Bend wire into U shape



3. Cut both ends of U shaped wire



4. Unscrew clamping lever by using 3mm allen wrench



5. Latch clamping lever half way on the lower handle



6. Tighten the screw on clamping lever
DO NOT OVERTIGHTEN THE SCREW



7. You are now ready to use your pinza rotary tying pliers.